

TacStar Magazine Extension

TacStar's Shotgun Magazine Extensions are made from steel, are super strong and guaranteed for life.

8-Shot extensions are currently available for Benelli, Mossberg and Remington and allow 3 extra rounds in the magazine tube.

7-Shot extensions are currently available for Benelli Nova/M-4, Winchester 1300 Defender and Remington 870/1100/11-87 and allow 2 extra rounds in the magazine tube. Minimum barrel length is 18 inches.

INSTALLATION INSTRUCTIONS

1. Make sure the shotgun (chamber and magazine tube) is UNLOADED.
2. Remove the barrel nut at the end of the magazine tube.
3. Using a screwdriver, carefully pry out the spring retainer at the end of the magazine tube. CAUTION: The spring is under tension, so be careful when removing retainer.
4. Replace the old spring with the new one.
5. Place the magazine extension over the end of the spring and compress until the threaded portion of the extension can be screwed onto the magazine tube. Tighten securely.

Remington 870 Wingmaster and 870 Express Models

Newer models of these shotguns require modification prior to the installation of the TacStar magazine tube extension. The new style shotguns do not use the magazine spring retainer clip of older models. Instead, a plastic cap is held in place by two dimples formed into the magazine tube retaining the magazine spring and providing the detent action for the magazine cap.

The two dimples must be removed before installation of the TacStar magazine tube extensions. The dimples extend into the magazine tube and prevent the ammunition and magazine follower from passing into the magazine tube extension.

To eliminate the dimples, use a Brownell's shotgun magazine tube dent remover or a round hand file and carefully remove the material.

Special Instructions for Mossberg 930 and 935

Some Mossberg 930 and 935 shotguns may be encountered that have a rolled over edge on the end of the factory magazine tube. This was done to help keep the factory spring retainer in place. This edge will need to be straightened before installing the extension. We would suggest a tapered tool, such as a wooden dowel with one end tapered, be used to straighten out this edge.

VISIT US AT WWW.TACSTAR.COM

TacStar® recommends that the user of this product be aware of and comply with local laws concerning restrictions in regard to firearm enhancements.