

INERTIA BULLET PULLER

Instructions

1. Loosen cap until chuck inside of cap accommodates round for easy entry. Insert and rotate cartridge until chuck engages cartridge extractor groove or comes into solid contact with rim or rimmed cartridge.
2. Tighten Bullet Puller cap.
3. Rap Bullet Puller against a hard, solid surface, cap end up, gripping handle mainly with thumb and forefinger. Remember, easier extraction results from handle and shaft being parallel to the surface struck at the moment of impact. In this position, the cartridge case is well aligned with the extraction force.

Note: The o-ring around the three piece chuck is split. The three pieces are crimped onto the o-ring as an assembly.