LYMAN QUICK SLICK CASE LUBE SPRAY

WARNING: Allowing excess lubricant in case may affect powder or primer.

Lyman "Quick Slick" Case Lube is a premium, fast-acting lubricant designed for use on cartridge cases prior to resizing. It eliminates messy lube pads and greasy fingers which lead to contaminated primers.

DIRECTIONS FOR USE:

Shake can before using. Periodically shake can for best results.

- 1. Disassemble sizing die and thoroughly clean inside the die with a solvent degreaser. Other lubricants form a protective barrier and can limit effectiveness.
- 2. Spray a light coat of Quick Slick inside the die and allow to dry. Reassemble sizing die.
- 3. Clean and inspect cartridge cases.
- 4. Place cartridge cases in a loading block or lay out in a single layer on a clean tray such as a cookie sheet or shallow cardboard box.
- 5. Spray lightly, roll cases over and spray lightly again. When using a loading block, spray one side of cases, reverse block and repeat on other side. Wait about 30 seconds. Cases are then ready to be resized.
- 6. After resizing, remove lubricant from cases. This can be done in a Lyman Turbo® Tumbler or Turbo Sonic® Ultrasonic cleaner, or by wiping the cases with a cloth.

DANGER: CONTENTS EXTREMELY FLAMMABLE AND UNDER PRESSURE. SKIN AND EYE IRRITANT. Store below 120° F, away from heat sources and out of direct sunlight. Use adequate ventilation. Do not puncture or incinerate container. Contains: Methyl Acetate (CAS#79-20-9), N-Hexane (CAS#110-54-3), Propane (CAS #74-98-6), N-Butane (CAS #106-97-8) and Isobutane (CAS #75-28-5). If sprayed in eyes, flush with water for 15 min. and seek medical attention. If sprayed on skin, wash with soap and water. If vapors are concentrated and inhaled, seek medical attention, may cause death or serious injury.

WARNING: This product can expose you to N-Hexane, which is known to the State of California to cause birth defects or other reproductive harm, and lead, which is known to the State of California to cause cancer, and birth defects or other reproductive harm. For more information go to www.p65warnings.ca.gov

MANUFACTURED IN USA FOR **LYMAN PRODUCTS**Middletown, CT 06457
1-800-22LYMAN
www.lymanproducts.com