

LYMAN QUICK SLICK CASE LUBE PUMP

Item# 7631298

WARNING: Allowing excess lubricant in cases may affect powder or primer.

DIRECTIONS FOR USE:

1. Disassemble sizing die and clean with a solvent degreaser. Other lubricants form a barrier and can limit effectiveness.
2. Spray a light coat of Quick Slick inside the die and allow to dry. Reassemble sizing die.
3. Clean and inspect cartridge cases.
4. Place cartridge cases in a loading block or lay out in a single layer on a clean tray such as a cookie sheet or shallow cardboard box.
5. Spray lightly, roll cases over and spray lightly again. When using a loading block, spray one side of cases, reverse block and repeat on other side. Wait about 30 seconds. Cases are then ready to be resized.
6. After resizing, remove lubricant from cases. This can be done in a Lyman Turbo® Tumbler or Turbo Sonic® Ultrasonic cleaner, or by wiping the cases with a cloth.

CONTAINS: N-Hexane (CAS #110-54-3), N-Butane (CAS #106-97-8), Isobutane (CAS #75-28-5), Propane (CAS #74-98-6), Molybdenum Disulphide (CAS #1317-33-5), Xylene (CAS #1330-20-7), Tetrabutyl Titanate (CAS #5593-70-4) and Sec-Butyl Alcohol (CAS #78-92-2).

DANGER: CONTENTS EXTREMELY FLAMMABLE AND UNDER PRESSURE. HARMFUL OR FATAL IF SWALLOWED. VAPOR HARMFUL. SKIN AND EYE IRRITANT.
Do not puncture or incinerate container. Do not expose to heat or store at temperatures above 120°F. Use only with adequate ventilation.

WARNING: Cancer and Reproductive Harm - www.P65Warnings.ca.gov

MANUFACTURED IN USA FOR
LYMAN PRODUCTS
Middletown, CT 06457
1-800-22LYMAN
www.lymanproducts.com