

Cartridge Case Solution

DIRECTIONS FOR USE:

- Fill ultrasonic unit with water to level specified by manufacturer.
- Open packet by cutting where shown with scissors.
- Add 1 packet for up to 20oz of water.
- Empty all packet contents into water.
- Tap water can be used, distilled water will improve results.
- Rinse parts with distilled water after cleaning.
- Allow cases to dry before use. After drying, cases may be tumbled in corn cob for brighter finish.
- Specifically designed to clean brass cases.
Do not use on other items. See caution below.
- Protect from freezing.

PRECAUTIONS:

- Do not ingest. • May cause skin irritation.
Wash residue from skin and clothing.
- First Aid: In case of eye contact, flush eyes with water and seek medical attention. If ingested, consult a physician.
- Keep out of reach of children.
- Contains Citric Acid (CAS#77-92-9)

IMPORTANT NOTICE TO PURCHASER:

The seller and/or manufacturer makes no guarantee about the outcome of the product's use as the use is beyond the control of the seller/manufacturer. User should read all directions and the information provided before using this product.

For use in cleaning items other than cartridge cases, a different solution must be used. For more information see our video at www.lymanproducts.com

Lyman Products Corp. • Middletown, CT 06457 • MADE IN U.S.A.
1-800-22LYMAN • www.lymanproducts.com
Not packaged for individual sale

Usage Chart

Model	No. of Packets
Lyman TS-700	1
Frankford Arsenal EZ	1
Hornady Lock-n-Load®	1
Hornady Lock-n-Load® 2L	2
Frankford Arsenal Extreme	2
Lyman TS-2500	2
RCBS Ultrasonic RC87055	3
Hornady Lock-n-Load® Magnum	3
Hornady Lock-n-Load® XL	4
Lyman TS-6000	4